
## HD01R

## Remote for ON/OFF sensors



## **Attention**

- 1.Please press "Reset" first if you want to change any setting.
- 2. When press any button, the light will flicker, it means the setting was recorded by the sensor.